



COMMUNICATORS

Cheap Talks!

We've simplified our popular Cheap Talk line of Augmentative Communicators. Now there are four basic models to choose from: Direct and Direct Jack & Say It Play It each with either Message Squares or Overlays.

Feature Descriptions:

Direct

Press one of the message squares and your pre-recorded message plays.

Levels

Each level can be used for a different topic. For example, the 6 Level communicator allows 6 levels of 8 different messages. One level can be about food, a second about health, and third about greetings, etc. (Please note: Communicators with levels cannot accommodate the Say It Play It (output) feature.)



Jacks

Jacks on unit allow you to attach capability switches that when activated, will play your pre-recorded messages. Say It Play It (output) jacks will activate devices.



Message Squares

Individual squares on the communicator. Individual icons can be placed under the plastic cover.



Overlay Option

A plastic frame is slotted allowing sheets of icons to be easily slipped in and out of the grid.



Say It Play It

Connect a toy or device to the jack and when the square is touched, it will activate your pre-recorded message and the toy or device.



KA3413

Cheap Talk 4 In-line 12-Levels

We have given you 12 levels. The total recording time is 288 seconds or 6 seconds per message. (48 messages total). Size: 12½" x 3" x 6". Requires 4 AA Batteries.

Direct w/Overlay Option

12 Level Cheap Talk 4 In-line KA3412

Direct & Jacks w/Overlay Option

Operates the same as our Direct model (above) but also has a slotted frame that allows easy replacement of sets of pictures. For use with up to 4 external switches.

12 Level Cheap Talk 4 In-line KA3413

Adjustable Mounting System

Easily mount your communicators!

Our new versatile mounting system goes from desktop to tabletop to wheelchair tray in seconds. Place the system where you want and use a C clamp (included) to hold the base plate in position. System holds up to 5 lbs. The "T" shaped slot in the aluminum base allows unlimited front to back and left to right adjustment. You can adjust the swivel arm to any position within its full 360 degree range. The swivel locks in place by tightening an easy-to-grasp knob. Weighs 3 lbs. Size: 12"L x 7"W x 5"H.

Adjustable Mounting System KA1012



Icons shown are not included (see page 8)



KA3054

Cheap Talk 4 In-line

Our popular Cheap Talk 4 with the message squares. Size: 12½" x 3" x 6". Requires 4 AA Batteries.

Direct

Activated by pressing one of the four squares, 5 seconds per message.

Cheap Talk 4 In-line Direct

KA3054

Direct w/Overlay Option

Operates the same as our Direct model (above) but also has a slotted frame that allows easy replacement of sets of pictures.

Cheap Talk 4 In-line Direct w/Overlay Option

KA6054

Direct, Jacks & Say It Play It

Activated by pressing one of the four message squares or by plugging external switches into the four input jacks on the side, 5 seconds per message. Additionally, two output jacks allow unit to activate two devices.

Cheap Talk 4 In-line Direct, Jacks & Say It Play It KA3055

Direct, Jacks & Say It Play It w/Overlay Option

Operates the same as #3055 (above) but also has a slotted frame that allows easy replacement of sets of pictures.

Cheap Talk 4 In-line Direct, Jacks & Say It Play It w/Overlay Option

KA6055