

Catalogue Number: SAURC

The **Technical Solutions TV/VCR Remote Switch Interface** features a universal infrared remote control unit (**URC 9050**) which can be programmed to control most remote controlled devices. Televisions, VCRs, CD players, Stereo systems and environment control systems can be controlled by the *Remote*.

Up to six external switches can be plugged into the **URC 9050**. These switches duplicate the functions of six of the standard small buttons on the **URC 9050**. The buttons associated with the switch sockets are as follows:

- The 'Power' Button
- The 'Volume Up' Button
- The 'Volume Down' Button
- The '1' Button
- The '2' Button
- The '3' Button



Setup

- Decide how many switches you wish to use with the **URC 9050**. – From 1 to 6 switches.
- Decide which socket/s and function/s you wish to access with your switch/es.
- Program the **URC 9050** to control your appliance (TV, etc.) see below.

You will need your existing remote control that works your TV, etc., as the **URC 9050** must learn the signals from the existing remote.

Brief instructions for programming the **URC 9050** can be found on the under side of the unit and more detailed instructions are enclosed. If you require any further assistance with the use of the **URC 9050** please contact Technical Solutions (03) 9737 9000.

Important

Remember that any button can be programmed to any function so you are not limited to the functions listed.

(E.g. the 'Power' Button could be programmed to operate the 'Mute' function as in example 2 below)

Two examples of programming options.

Using 3 switches plugged into 'Power', 'Volume Up' and 'Volume Down':

1. Program the three buttons to 'Power', 'Volume Up' and 'Volume Down'.
- OR
2. Program the three buttons to 'Mute', 'Channel Up' and 'Channel Down'.